

# **SpinQuest Target Overview** E1039 Polarized target system and cryogenics

**D. Keller** 

# **Expected Uncertainties**

- Statistical: 3%-5% absolute error
  - Dependent on polarization, dilution, events
  - Dependent on run time
- Systematic: Mostly relative error, some absolute.
   Numbers listed hopeful upper bounds
  - Target: ~6/7% (P/D)
    - Dilution: 3%
    - Packing Fraction: 2%
    - Density: 1%
    - Polarization: 2.5%/4.5% (P/D)
    - Polarization Homogeneity: 2%
    - Uneven Decay: 3%
    - Alignment: small absolute possible
  - o Beam: 2.5%
    - Relative Luminosity: 1%
    - Drifts: 2% (Absolute possible)
    - Scraping: 1%
  - Detector: 1% (Some relative, Absolute possible)





- Dynamic Nuclear Polarization
  - Dope target material with paramagnetic centers:

chemical or irradiation doping to just the right density (1019 spins/cm3)

- Polarize the centers: Just stick it in a magnetic field


- Use microwaves to transfer this polarization to nuclei: mutual electron-proton spin flips re-arrange the nuclear Zeeman populations to favor one spin state over the other

 Optimize so that DNP is performed at B/T conditions where electron t<sub>1</sub> is short (ms) and nuclear t<sub>1</sub> is long (minutes or hours)


$$P_{TE} = \frac{e^{\frac{\mu B}{kT}} - e^{\frac{-\mu B}{kT}}}{e^{\frac{\mu B}{kT}} + e^{\frac{-\mu B}{kT}}} = \tanh\left(\frac{\mu}{\mu}\right)$$

### Successful material for DNP characterized by three measures:

- 1. Maximum polarization
- Dilution factor
- Resistance to ionizing radiation







# **Polarized Target Subsystems**

Fridge

UVA-LANL: Three completely new NMRs



NMR

cerikon O Pumps

14,000 providing the highest cooling power for 1K system

> UVA: Configure Fridge O and Insert, Commission for Optimal running, setup with Actuator



LHe



Microwave



UVA: Tune System and Automation



National Institute of Standards and Technology U.S. Department of Commerce



Target material UVA: Target Insert with longest cell at 8 cm for 5T







UVA: Commissioning, Slow Controls, Quench Study,

Material	Dens. (g/cm <sup>3</sup> )	Length (cm)	Interaction Length (cm)	Dilution Factor	Packing Fraction	$\langle P_z \rangle$
NH <sub>3</sub>	0.867	7.9	91.7	0.176	0.6	80%
$ND_3$	1.007	7.9	82.9	0.3	0.6	32%


- 3 probes over length of target.
- NMR expected to have 2-3% error for proton 4-5% for deuteron. Deuteron signal order of magnitude smaller.
- If coils moved outside cup, possible increase in uncertainty for deuteron.
- Need time to thermalize. Need 3xt1 (relaxation rate, ~10 min for proton, 1 hour for deuteron). 2-3x more error if rushed.
- Built-in error for neutron polarization from deuteron.





Material	Dens. (g/cm <sup>3</sup> )	Length (cm)	Interaction Length (cm)	Dilution Factor	Packing Fraction	$\langle P_z \rangle$
NH <sub>3</sub>	0.867	7.9	91.7	0.176	0.6	80%
$ND_3$	1.007	7.9	82.9	0.3	0.6	32%

- 3 probes over length of target.
- proton 4-5% for deuteron. Deuteron signal order of magnitude smaller.
- If coils moved outside cup, possible
- Need time to thermalize. Need 3xt1 rushed.
- from deuteron.



### **SpinQuest** A target system to operate at the proton intensity frontier

- At least  $3 \times 10^{12}$  protons/spill
- 8 cm long target of NH<sub>3</sub> and ND<sub>3</sub>
- Several Watts of cooling available: 14000 m<sup>3</sup>/hour pump
- 5T vertically pointing field (close to critical temperature each spill)
- Luminosity of  $2 \times 10^{35}$  cm<sup>-2</sup>s<sup>-1</sup>


## **Target Insert**


Carbon fiber with copper heat sink

20X27 mm elliptical cells

long cell length microwave horn








- 3 NMR coils per cell
- 8 cm long target cell of solid: NH<sub>3</sub> and ND<sub>3</sub>
- Standard Insert has 3 cells
- One centering cell
- Elliptically shaped to match profile

# Last Target Polarization at UVA






# **Superconducting Magnet**



### Introduction: Quench definition



The critical surface is defined from the temperature (T), magnetic field (B), and the surface current (J)

Magnet quench if the T, B or J lie outside the critical surface

For B = 5 T, The maximum temperature that the magnet can hold is around 7.2 K

### **Quench Studies Primary Intensity Boundary**

- Very Limited Experimental Information
- Use Monte Carlo and Finite Element Analysis
- Match Measured Field and Simulated Field

•	PUMP	BEFORE SYSTEMATIC STUDIES (PROTON/SEC)	AFTER SYSTEMATIC STUDIES (PROTON/SEC)
	No pumping	$1 \times 10^{12}$	$0.85 \times 10^{12}$
•	KNF-N0150	3.2 × 10 <sup>12</sup>	2.7 x 10 <sup>12</sup>


Use Loundle to make Quench Commissioning Plan

https://confluence.its.virginia.edu/display/twist/Quench+Commissioning

### coils


### Running

### Approximation Strategy




Third, we parameterize some of the unknown properties by the effective surfaces that are in direct contact with the LHe:

- Perimeter of the He void
- Insulation
- Former



Second, we consider the superconducting magnet as a composite material with the effective thermal parameter



Rayleigh's formula

$$\frac{k_{eff}}{k_m} = 1 + \frac{3\phi}{\left(\frac{k_1 - 2k_m}{k_1 - k_m}\right) - \phi + 1.569\left(\frac{k_1 - k_m}{3k_1 - 4k_m}\right)\phi^{\frac{30}{3}} + \dots}$$


Rayleigh's model consist of parallel cylinders embedded in a continuous matrix

# Field Measurement and Map

Measure Homogeneity using NMR and Hall Probe


### Accurate Field Map

We achieve a high level of homogeneity around the target area & along the beam line:




### High level of homogeneity in the target area


Measure outside fringe field and map to simulated field





# $Geant \rightarrow COMSOL$



## Collimator








## Magnet Comparison






### Solidworks → Geat4 Based on drawings and measurements


Then look at energy

# **Quench Simulations**

### What we have currently




Maximum hot spot around 18000 W/m^3 Former



### Results on BNL experiment

The maximum temperature of the coil as a function of time




- Maximum Temperature profile Tmax(t) for BNL:
  - 24 GeV proton
  - 2ell proton/s
  - Teflon Target

### Notes:

- The BNL magnet was quenched in this setup (Teflon target & 2e11 proton/s)
- The simulation results "indicate" quench -> The heat is accumulated over time
- There is an issue about numerical convergence issue for longer run that need to be fixed -> require extremely fine Mesh and time step

# SpinQuest Target Magnet



Maximum Temperature profile Tmax(t) for E1039:

- 120 GeV proton
- le12 proton/s
- NH3 Target

Conclusion: It is save to run at 1e12 proton/s but I recommend this intensity to be considered as the upper limit

# **Superconducting Magnet Quest Studies**

### SpinQuest

- Cycle Time: Every 55.6 seconds
- Spill Length: 4.4 seconds
- Beam Intensity: 1.0X10<sup>12</sup> protons/sec

### Limiting Factors: - Fridge Cooling Power

- Heat load to SC Magnet
- Cycle Time

Highest Cooling Power DNP Evaporation System:

- Running at 20 SLPM have 1.4 W of cooling power
  - For 4.4 sec receive 0.4 W of heat load from protons
  - Continuous DNP microwave heat load 0.65 W
- Super conducting magnet critical temperature 7.5 K @ 5T
- Cycle gives time to cool

BNL:

٧S


Energy	24 GeV		
Cycle Time	3 seconds		
Spill Length	1 second		
Beam Intensity	$2 \times 10^{11}$ protons/pulse		

BNL : 4.0X10<sup>12</sup> protons/min - 4 cm FNAL: 5-4.4X10<sup>12</sup> protons/min - 8 cm

## Systematic Uncertainties

Subsystem	Systematics	ΔTmax/Tmax (No pump)	ΔTmax/Tmax (KNF Pump)
Heat transferred to the LHe			
Coefficient uncertainty	50 %	0.7 %	1.1 %
<ul> <li>Contact-surface area</li> </ul>	50 %	0.7 %	1.1 %
<b>COMSOL Simulation</b>			
• Mesh	Normal, fine, extra fine	0.79 %	0.8 %
Time Step	Δt = 0.05 0.001	Negligible	Negligible
Geant fitting	10%	2.6 %	3.1 %
TOTAL		4.5 %	5.8 %
		6.1 K +/- 0.27 K	6.1 K +/- 0.35 K

## **External Magnet Temp Sensor**




### Type-T Thermocouples Cu-CuNi

### **Estimated Quench Threshold Based on a series of MC systematics studies**


- Assume no other intensity constraints
- Assume unlimited LHe

PUMP	BEFORE SYSTEMATIC STUDIES (PROTON/SEC)	AFTER SYSTEMATIC STUDIES (PROTON/SEC)
No pumping	$1 \times 10^{12}$	0.85 x 10 <sup>12</sup>
KNF-N0150	3.2 × 10 <sup>12</sup>	2.7 x 10 <sup>12</sup>

# SpinQuest Experimental Hall



# NM4 Experimental Hall









# **Top of Target Cave**









# **Target Alcove**



# **Overhead view of Cryo-platform**




## **Full Detector and Target**






### **Helium and Nitrogen Supplies**






## West View of Target Cave





### **QT Liquefier** Set of components



### **Quantum Technology Corp Liquefier A DOE-UVA Purchase for SpinQuest**

### **Model QDHRR100 Helium liquefier**

Liquefaction Rate: 100 liters/day Dewar Capacity: 250 Liters Compressor Package Model (five units): QDC6000V (Available water cooled only) Compressor Package Weight: 1320 LB Power Consumption: 37.5 kW 3 Phase 480V / 60Hz Cooling Water: Minimum flow 9.5 GPM @ 80°F Ambient Temperature Range: 45°F to 100°F (7 to 38°C) Gaseous helium requirement: Purity 99.99%

- Quntumpure Purifier
- Helium Gas Purity Meter
- Custom liquid helium transfer line
- Custom liquefier and liquid helium transfer system  $\bullet$

2 units, for a total of 200 LPD

# Liquefier System

Liq	uefier	Production @6psi/day	Boil-off dewars (2 x250L) (1.15%/day)	Transfer line cooling	Transfer line flow 1/2h*	Flash boil-off (11%)**	Expected He transferred
		[L]	[L]	[L]	[L]	[L]	[L]
200/day	upper bound	220	6	4	16	24	170
200/day	lower bound	200	8	10	20	22	140


- Requested 135 L/day at the target magnet (67% efficient when transferring over 60 min.)
- Based on studies at UVA this is more than sufficient for continuous running with no beam
- Additional pumping on the magnet will likely be required to run at the beam intensity of interest
- Less efficiency is expected due to safety modification of system, magnet and fridge
- These numbers are very much dependent on the efficiency of the transfer line meeting expectation

### Liquid Helium Transfer **QT** Transfer to the target

- Initial Cooldown 100% boil-off at 1700 slpm
- QT recovery compressor can handle 1500 slpm lacksquare
- Loss of 200 slpm lacksquare
- Using rigid non-LN2 shielded (just vacuum) with flexible ends
- Initial fill at 80K requires at least the full 500L of stored LHe
- Refill ~135L (200L) should be delivered over 60 minutes
- Can only store 2X250 at a time



## **QT Transfer Line into Cave**




### FULL ASSEMBLY OF TRANSFER LINE


EVERY SECTION NEEDS A VACUUM PORT FOR THE INSULATION AND


United Line of Surfac All Die	Officerwise 38th Tol: #8.2, Ang # Pittink tensions: In	ledi ukar hal: <b>0.5"</b>		IDENTIAL	Projection Method THIRD ANGLE		rechnology	8-11-27
CHINA CHICS AFFVO	HAAE EAMAUELL	Information or	DA38 3018-02-38	I) DEBURK AN	0 BREHRIBHARF EDGES	P504 - TR LINE S		R
descrip and free at Qua DISCL part or	This clowing and any internation or descriptive material set out on it are the confidential and copyright property of Countering and MLBT NOT BE DISCLOSED, COPIED, LOANED in whole or part or used for any purpose without the written permission of Quantum Technology.			MATERIAL BIER	N/A N/A	P504-TL-00		43

### **Target Magnet Pumping** Intensity vs Helium budget

Intensity	$3 \times 10^{12} p/s$	$10 \times 10^{12} p/s$
Daily Consumption	135 l/day	175 l/day
Additional Daily Requirements	01	40 l/day
<b>250L</b>	0	5 days







### Cryosystem status

### • Target

*Roots pump*: Electrical work likely complete
 LCW setup near complete
 Leak check complete
 ORC writeup in process

Target Slow Controls: LabView Meeting- Organize subsystem, Readout/control, NMR system, Microwave, Actuator, cryocontrols Electronics\interlocks- separate effort to come

Target Magnet: In place
 Final survey is week after next
 Vacuum piping to come
 Access walkway to come
 Electrical through West penetration to come

Refrigerator : Preparing system for safety modifications Back to UVA for machining Install hopefully around late Oct

QT Liquefier: Everything in place
 Several system connections still required
 Helium + Nitrogen lines must be in place (FNAL+UVA)
 Can not yet arrange for QT visit (COVID-19)

### **Target Team UVA Spin Physics and Polarized Target Group**

- Team Leader
- Research Scientist (hiring in process)
- 2 postdocs
- Slow Controls
- 1 Target Technician (hiring in process)
- 3 grad students
- undergrads

### Challenges Past and Present

- No full-time cryo-engineer to help prepare for FNAL cryosafety review
- Major infrastructure additions/modification to meet safety standards
- Additional modifications driven by safety still in process
- FNAL Cryo-engineers can not guarantee a pass (at any price)
- Training target experts requires a running target